

ATTACCHI SPECIFICI PER - SPECIFIC FITTING KIT FOR  
 KIT DE MONTAGE SPECIFIQUE POUR - SPEZIFISCHER MONTAGEKIT FÜR  
 ANCLAJE ESPECIFICO PARA

**YAMAHA MAJESTY 125/150 '01/'02**  
**MBK SKYLINER 125/150 '01/'02**

ISTRUZIONI DI MONTAGGIO - MOUNTING INSTRUCTIONS  
 INSTRUCTIONS DE MONTAGE - BAUANLEITUNG - INSTRUCCIONES DE MONTAJE

© Copyright 26072003-Rev02, 1/1

1



**PIASTRINA**  
 LITTLE PLATE  
 PLAQUETTE  
 HALTERUNGEN  
 PLETINA

**Q.TY n.4**

2



**MOUSSE ADESIVA**  
 RUBBER  
 GOMME  
 MOUSSEGUMMI  
 GOMA

**Q.TY n.4**

3



**VITE ORIGINALE**  
 ORIGINAL SCREW  
 VIS D'ORIGIN  
 ORIGINAL SCHRAUBE  
 TORNILLO ORIGINAL

**Q.TY n.-**

4



**DISTANZIALE ORIGINALE**  
 ORIGINAL SPACER  
 ENTRETOISE ORIGINAL  
 ORIGINAL DISTANZSTÜCK  
 DISTANCIADOR ORIGINAL

**Q.TY n.-**

5



**PASSACAVO IN GOMMA ORIGINALE**  
 FAIRLEADER  
 CHALIMARD  
 GUMMI  
 FUNDA

**Q.TY n.-**

INCOLLARE LA MOUSSE SULLE 4 PIASTRINE  
 STICK THE WEDGESPACER TO THE FOUR PLATES  
 COLLER LA MOUSSE SUR LES PLAQUETTES  
 KLEBEN SIE DEN MOUSSEGUMMI AN DIE VIER HALTERUNGEN  
 PEGAR LAS GOMAS A LAS PLETINAS

